

JB
1735
BLANCPAIN
MANUFACTURE DE HAUTE HORLOGERIE

Your watch

**CALENDAR MOON PHASES, SECONDS, SECURED
MOVEMENT, SELF-WINDING
CALIBRE 913QL.P, UP TO 40-HOUR AUTONOMY.**



6126-1127 / 6126-3642



6126-2987 / 6126-4628

The 6126-2987 and 6126-4628 watch models are adjusted in the same way.

THE CROWN HAS TWO DISTINCT POSITIONS:

Position A, crown in manual-winding position.

Position B, crown pulled out to time-setting position, enabling adjustment of the hours and minutes. In this position the seconds hand can be locked by turning the crown very slightly backwards, enabling the watch to be synchronised with an hour signal.

Push the crown back in to position A once the time has been set.

FAST CALENDAR ADJUSTMENTS:

The stylus supplied with the watch is designed to actuate correctors 1 and 2 located on the circumference of the case.

1. To adjust the date: corrector 1, located at 10 o'clock
2. To adjust the moon phases: place the disc in the full-moon position by means of corrector 2 located at 8 o'clock. Check the date of the last full moon using a lunar calendar. Press corrector 2 the same number of times as the days that have elapsed since the last full moon.

DUAL-PURPOSE BLANCPAIN TOOL

1. Correction stylus
2. Screwdriver for triple-blade safety folding clasp.

The adjustable tip of your Blancpain tool is initially turned to the “screwdriver” side to adjust the triple-blade safety folding clasp.

This tool also serves as a correction stylus when adjusting the settings on your watch. To do this, slide one finger into the notch and pull until the adjustable tip comes loose. Turn the tip to the “stylus” side and place it back in position with the sphere-shaped end facing the slot. Press it in with a slight rotating movement to secure it.



TRIPLE-BLADE FOLDING CLASP (WITH PRONG)

Only Blancpain straps specially designed for this folding clasp should be used. For your safety and comfort, we advise you to have your new clasp fitted by an authorised Blancpain retailer. You can always then adjust the length of the wristband yourself.

OPENING

To open the fastening, place one finger on each side of the clasp and pull it upwards (Fig. 1). Proceed in the same manner to open the other blade (Fig. 2).



Fig. 1



Fig. 2

CLOSING

Slip your Blancpain watch on your wrist and close the folding blades as indicated on figures 3 and 4.



Fig. 3



Fig. 4

ADJUSTING THE STRAP:

Slide the section of the strap into the clasp and insert the prong into the desired hole (Fig. 5). Move the prong to another hole if necessary.



Fig. 5

IMPORTANT

Please do not pull the end of the strap upward to open the fastening as the prong might come completely out of the hole, meaning the watch would no longer be held and might fall.

