

JB
1735
BLANCPAIN
MANUFACTURE DE HAUTE HORLOGERIE

Your watch



**COMPLETE CALENDAR, MOON PHASES,
SMALL SECONDS, SELF-WINDING
CALIBRE 6763, UP TO 100-HOUR AUTONOMY.**



3663A

WATCH MODEL 3663 IS CORRECTED IN THE SAME WAY.

THE CROWN HAS TWO DISTINCT POSITIONS:

Position A, crown in manual-winding position.

Position B, crown pulled out to time-setting position, enabling adjustment of the hours and minutes.

Push the crown back in to position A after the adjustment.

CALENDAR ADJUSTMENTS:

The stylus supplied with the watch is designed to actuate correctors 1, 2, 3 and 4 located on the circumference of the case.

1. Position B, crown pulled out to hand-setting position: set the watch at 6 pm and not 6 am! This is important!
2. Adjust the date to that preceding the desired date, corrector 2, located at 4 o'clock.
3. Adjust the day to that preceding the desired day, corrector 4, located at 10 o'clock.
4. Adjust the desired month, corrector 1, located at 2 o'clock.
5. Adjust the moon-phase indicator: place the disc in the full-moon position, corrector 3, located at 8 o'clock. Determine the date of the last full moon using a calendar. Press corrector 3 as many times as days have elapsed since the last full moon, until that preceding the desired day.
6. Position B, serves to make the calendar jump and to correct the hours and minutes. Push the crown back into position A after the adjustment.

IMPORTANT

To avoid damaging the mechanism, no correction must be performed after setting the time by turning the hands counter-clockwise (SIAM).

**Do not actuate correctors 1-2-4 between 10 pm and 3 am the next day.
Do not actuate corrector 3 between 10 am and 2 pm.**

TRIPLE-BLADE FOLDING CLASP (WITH PRONG)

Only Blancpain wristbands specially designed for this folding clasp should be used. For your safety and comfort, we advise you to have your new clasp fitted by an authorised Blancpain retailer. You can always then adjust the length of the wristband yourself.

OPENING

To open the fastening, place one finger on each side of the clasp and pull it upwards (Fig. 1). Proceed in the same manner to open the other blade (Fig. 2).



Fig. 1



Fig. 2

CLOSING

Slip your Blancpain watch on your wrist and close the folding blades as indicated on figures 3 and 4.



Fig. 3



Fig. 4

ADJUSTING THE WRISTBAND:

Slide the section of the wristband into the clasp and insert the prong into the desired hole (Fig. 5). Move the prong to another hole if necessary.



Fig. 5