

Your watch

ULTRA-SLIM, POWER-RESERVE INDICATION ON THE BRIDGE SIDE, HAND-WINDING

CALIBRE 11A4B, UP TO 100-HOUR AUTONOMY.

THE CROWN HAS TWO DISTINCT POSITIONS:

Position A, crown in manual-winding position.

 $\ensuremath{\text{Position}}\xspace$ B, crown pulled out to time-setting position, enabling adjustment of the hours and minutes.

Push the crown back in to position A once the time has been set.



6605-1127 / 6605-3642 / 6605-3440

DUAL-PURPOSE BLANCPAIN TOOL

- 1. Correction stylus
- 2. Screwdriver for triple-blade safety folding clasp.

The adjustable tip of your Blancpain tool is initially turned to the "srewdriver" side to adjust the triple-blade safety folding clasp.

This tool also serves as a correction stylus when adjusting the settings on your watch. To do this, slide one finger into the notch and pull until the adjustable tip comes loose. Turn the tip to the "stylus" side and place it back in position with the sphere-shaped end facing the slot. Press it in with a slight rotating movement to secure it.





TRIPLE-BLADE FOLDING CLASP (WITH PRONG)

Only Blancpain straps specially designed for this folding clasp should be used. For your safety and comfort, we advise you to have your new clasp fitted by an authorised Blancpain retailer. You can always then adjust the length of the wristband yourself.

OPENING

To open the fastening, place one finger on each side of the clasp and pull it upwards (Fig. 1). Proceed in the same manner to open the other blade (Fig. 2).





Fig. 1

Fig. 2

ADJUSTING THE STRAP:

Slide the section of the strap into the clasp and insert the prong into the desired hole (Fig. 5). Move the prong to another hole if necessary.



IMPORTANT

Please do not pull the end of the strap upward to open the fastening as the prong might come completely out of the hole, meaning the watch would no longer be held and might fall.

CLOSING

Slip your Blancpain watch on your wrist and close the folding blades as indicated on figures 3 and 4.



Fig. 3



Fig. 4