

JB
1735
BLANCPAIN
MANUFACTURE DE HAUTE HORLOGERIE

Your watch



**DOUBLE TIMEZONE, DATE AND SMALL SECONDS, DAY/
NIGHT INDICATION, SELF-WINDING
CALIBRE 5L60, UP TO 100-HOUR AUTONOMY**



3760-1954L



3760-1144L

Watch model **3760-1144L** is adjusted in the same way.

Kindly unscrew the crown (position A) before performing any corrections, and screw it in again once the watch has been adjusted.

The day/night indicator enables you to know whether your place of residence (small counter at 12 o'clock) refers to a daytime or night-time hour.

THE CROWN HAS THREE DISTINCT POSITIONS:

Position A, crown in manual-winding position.

Position B, enabling time-zone (local time) setting and fast date-setting (only the hour hand turns) : for rapid date adjustment, both forwards and backwards. Do not make date changes between 8 pm and 1 am

Position C, crown pulled out to the position for setting the time of your place of residence: for adjustment of hours and minutes.

Push the crown back into position A once the hands have been set and screw the crown in as far as the stop.

TRIPLE-BLADE FOLDING CLASP (WITH PRONG)

Only Blancpain wristbands specially designed for this folding clasp should be used. For your safety and comfort, we advise you to have your new clasp fitted by an authorised Blancpain retailer. You can always then adjust the length of the wristband yourself.

OPENING

To open the fastening, place one finger on each side of the clasp and pull it upwards (Fig. 1). Proceed in the same manner to open the other blade (Fig. 2).



Fig. 1




Fig. 2

CLOSING

Slip your Blancpain watch on your wrist and close the folding blades as indicated on figures 3 and 4.



Fig. 3



Fig. 4

ADJUSTING THE WRISTBAND:

Slide the section of the wristband into the clasp and insert the prong into the desired hole (Fig. 5). Move the prong to another hole if necessary.



Fig. 5