

**JB**  
**1735**  
**BLANCPAIN**  
MANUFACTURE DE HAUTE HORLOGERIE

Your watch



**8 DAY HALF-TIMEZONE, DATE, DAY / NIGHT INDICATION,  
SECURED MOVEMENT, SELF-WINDING**

CALIBRE 5235DF, UP TO 192-HOUR AUTONOMY (REF. 6661)

CALIBRE 5254DF, UP TO 72-HOUR AUTONOMY (REF. 6660, 6665)



6661

**THE CROWN HAS THREE DISTINCT POSITIONS AND A PUSHBUTTON:**

The pushbutton located on the crown serves to select either date or time-zone correction.

**Position A**, crown in manual-winding position.

**Position B**, crown pulled out to the position for GMT time-setting or fast-date adjustment: when seeking to perform a fast date adjustment, a time zone marked off from 10 pm to 2 am indicates that it cannot be corrected.

Such a manoeuvre does not actually cause any damage, but prevents any correction of the date.

**Position C**, crown pulled out to the time-setting position: serves to correct the reference hours and minutes (12 o'clock subdial) as well as the day/night indication.

THE 6660 AND 6665 WATCH MODELS ARE ADJUSTED IN THE SAME WAY.

## TRIPLE-BLADE FOLDING CLASP (WITH PRONG)

Only Blancpain wristbands specially designed for this folding clasp should be used. For your safety and comfort, we advise you to have your new clasp fitted by an authorised Blancpain retailer. You can always then adjust the length of the wristband yourself.

### OPENING

To open the fastening, place one finger on each side of the clasp and pull it upwards (Fig. 1). Proceed in the same manner to open the other blade (Fig. 2).



Fig. 1



Fig. 2

### CLOSING

Slip your Blancpain watch on your wrist and close the folding blades as indicated on figures 3 and 4.



Fig. 3



Fig. 4

### ADJUSTING THE WRISTBAND:

Slide the section of the wristband into the clasp and insert the prong into the desired hole (Fig. 5). Move the prong to another hole if necessary.



Fig. 5