

JB
1735
BLANCPAIN
MANUFACTURE DE HAUTE HORLOGERIE

Your watch



MINUTE REPEATER, SELF-WINDING CALIBRE 35, UP TO 40-HOUR AUTONOMY.



THE CROWN HAS TWO DISTINCT POSITIONS:

Position A, crown in manual-winding position. The crown does not lock at the end of the winding process, but instead turns freely, thereby preventing any damage to the movement.

Position B, crown pulled out to time-setting position, enabling adjustment of the hours and minutes.

The time-setting must be done in a clockwise direction in order to ensure that the indications respectively given by the hands and the striking mechanism agree. When the time is set in a counter-clockwise direction, bring the hands back to the correct time, then turn them one more hour backwards, before finally returning to the desired time.

This manoeuvre is necessary in order to avoid a discrepancy between the indication given by the minutes hand and that given by the striking mechanism due to the gearing of the time-setting system.

Push the crown back in to position A once the time has been set.

MINUTE REPEATER WINDING LEVER:

Push the winding lever towards the 12 o'clock position and your watch will strike hours, quarter-hours and minutes.

The winding lever travel will change depending on the hour shown.

IMPORTANT

To avoid damaging certain parts, never set the time while the watch is chiming. Also await the end of the chiming and above all the complete winding down of the striking mechanism before again activating the winding lever or slidepiece.

TRIPLE-BLADE FOLDING CLASP (WITH PRONG)

Only Blancpain wristbands specially designed for this folding clasp should be used. For your safety and comfort, we advise you to have your new clasp fitted by an authorised Blancpain retailer. You can always then adjust the length of the wristband yourself.

OPENING

To open the fastening, place one finger on each side of the clasp and pull it upwards (Fig. 1). Proceed in the same manner to open the other blade (Fig. 2).



Fig. 1



Fig. 2

CLOSING

Slip your Blancpain watch on your wrist and close the folding blades as indicated on figures 3 and 4.



Fig. 3



Fig. 4

ADJUSTING THE WRISTBAND:

Slide the section of the wristband into the clasp and insert the prong into the desired hole (Fig. 5). Move the prong to another hole if necessary.



Fig. 5